

Rugged Tablet

- TB162 -



Quick Start Guide

V1.4

Package


Please make sure the following contents are in the TB162 gift box.

If something is missing or damaged, please contact your Unitech representative.

The basic package contents


- TB162 Tablet Computer
- AC/DC adapter and AC power cord
- Quick Start Guide

Product View



1	Front Camera
2	Internal Microphone
3	Touch Screen
4	Headphone Jack
5	Volume Up / Volume Down Button
6	Barcode scanner (optional)
7	Power Button
8	Micro HDMI Port
9	USB 3.0 Port
10	DC-in Jack
11	Reset Hole
12	USB 3.0 Port
13	RJ-45 Connector
14	Dock Connector
15	Boss Hole





17	Rear Camera
18	Battery Latch
19	Speaker
20	Barcode Scanner Trigger

Getting Started

Before starting to use the tablet PC, we would like to suggest you follow the illustrations below to begin to use the tablet PC.



CAUTION!

- Please fully charge the battery before using it for the first time.
- To ensure the unit working properly, please keep all connectors away
 from the contaminants staying inside of them such as dust, grease, mud,
 and water. The negligence may cause the unit with no communication,
 short circuited, overheated and so on.
- If the connector is damaged, please ensure the connector is being fully repaired before using the unit to avoid causing short circuited.



http://www.ute.com/