

Factory Default




Report Software Version



USB Device Type



HID Keyboard Emulation



USB Virtual COM

Quick Keypad Emulation



Enable



*Disable

Beeper Volume



Low Volume



Medium Volume



* High Volume



Auto Aim



Auto Aim with Illumination

Trigger Modes



*Standard (Level)



Presentation (Blink)



Host

Interleaved 2 of 5 (ITF)



Enable Interleaved 2 of 5



*Disable Interleaved 2 of 5

UPC-A



*Enable UPC-A

UPC-E



*Enable UPC-E



Disable UPC-E



Disable UPC-A

Decode UPC/EAN/
JAN Supplementals



Decode UPC/EAN/JAN Only With Supplementals



*Ignore Supplementals



Autodiscriminate UPC/EAN/JAN Supplementals

EAN-8/JAN-8



*Enable EAN-8/JAN-8



Disable EAN-8/JAN-8

EAN-13/JAN-13



*Enable EAN-13/JAN-13



Disable EAN-13/JAN-13

Code 39



*Enable Code 39



Disable Code 39

Enable/Disable GS1-128



*Enable GS1-128



Disable GS1-128

Code 128



*Enable Code 128



Disable Code 128

Codabar (NW-7)



Enable Codabar



*Disable Codabar

Maxicode



Enable Maxicode



*Disable Maxicode

QR Code



*Enable QR Code



Disable QR Code

Data Matrix



*Enable Data Matrix



Disable Data Matrix

PDF417



*Enable PDF417



Disable PDF417