

MS852 / MS852Plus Auto Switching

2D Imager Barcode Scanner Quick Start Guide

Auto Switching



Connecting the Scanner

Connect USB cable to the USB port of a host PC.



USB Device Type

HID Keyboard*



CDC (SPP)



Factory Default



Display F/W Version



Auto Sense

Enable Auto Sensing *



Disable Auto Sensing (Trigger Mode)



Encoding

Remark: For displaying Traditional Chinese character on your Windows PC, please scan the QR code below to look for corresponding product name and download Windows registry setting utility for Traditional Chinese input.

UTF-8*



Big 5



Good Read

Good Read Beep Enable*



Good Read Beep Disable







MS852 / MS852 Plus Auto Switching

2D Imager Barcode Scanner Quick Start Guide

HID Keyboard Character Delay

1 ms*





5 ms



50 ms



10 ms



100 ms



HID Keyboard Block Delay

10 ms*



500 ms



50 ms



1 Sec.



100 ms



3 Sec.



HID Keyboard Case

Auto Trace*



To Lower



To Upper



HID Keyboard Language

French

US English*

UK English





Swiss



Danish



Swedish

Spanish



Norwegian



Partial ALT



German



Japanese

